

綜合數碼電視 (iDTV) 數碼廣播頻道調諧指南：Samsung
iDTV DTT Channel Auto-Tuning Operation Instruction: Samsung

1

按「MENU」鍵進入「主目錄」
Press “MENU” key to access
“Main Menu”




遙控器



電視畫面

2


按「向下」鍵以選擇「頻道」
Press “DOWN” key to select
“Channel”



3

按「」鍵進入「頻道」目錄


Press “” key to access “Channel” menu



4

按「向下」鍵選擇「自動選台」


Press “DOWN” key to select “Auto Store”



5

按「」鍵進入「自動選台」目錄。系統會要求「選擇需要記憶的天線」，請選擇與「無線」相對的「開始」選項

Press “” key to access “Auto Store” Menu. The system will ask for “Selecting the antenna connection”. Choose “Start” option next to “Air” (stand for Air antenna signal)




選擇無線執行自動選台功能。

6

按「」鍵確認

Press “” key to confirm





選擇數位和模擬。



7

系統會要求「選擇要記住的頻道類型」，按「向下」鍵選擇與「數位」相對的「開始」選項


The system will ask for “The type of channels to be memorized” Press “DOWN” key to choose “Start” option next to “Digital” to confirm the type of channels



8

按「」鍵確認，「自動選台」程序便會即時啟動，請等待直至選台程序完成

Press “” key to start the “Auto-Tuning” procedure. Please wait until the procedure is completed



「自動選台」程序完成後，所有目錄會自動關閉並恢復播放電視節目，觀眾可選擇收看明珠台或其他頻道。

Once the “Auto-Tuning” procedure is completed, the menu will be closed automatically and TV programmes will be resumed. Audience can choose watching Pearl or other channels.

